MEE1005 Materials Engineering and Technology B1+TB1

- **1.** Draw a hypothetical eutectic phase diagram A-B with the help of following data:
- Melting point of $A = 900^{\circ} C$.
- Melting point of B = 800° C.
- Eutectic reaction occurs at 700°C at 50% B composition.
- \cdot Maximum solubility of B in A and A in B at eutectic temperature is 20% and 10 % respectively which drops to zero at 0°C.
- (i) Mark each line and area.
- (ii) Write the invariant reaction with composition that occurs.
- (iii) If eutectic alloy is cooled from liquid to just below the eutectic temperature, calculate the amount of each phase at just below the eutectic temperature.
- **2.** For a hypo-eutectoid steel of 0.3 wt% carbon, calculate the following: (i) the amount of austenite and proeutectoid phase, just above the eutectoid temperature; (ii) the amount of ferrite and cementite just below the eutectoid temperature. Draw microstructure of this steel just above the eutectoid temperature and at room temperature and explain the microstructural evolution.
- **3.** Using T-T-T diagram for an eutectoid steel alloy, determine the final microstructure of a small specimen subjected to the following time temperature treatments. In each case the specimen begins at 800°C and that has been held at this temperature long enough to have achieved a complete and homogeneous austenitic structure:
- (a) Rapidly cool to 250°C, hold for 960 s, then quench to room temperature
- (b) Rapidly cool to 600°C, hold for 7 s, then quench to room temperature
- (c) Rapidly cool to 400°C, hold for hold for 1000s, then quench to room temperature
- (d) Rapidly cool to 700°C, hold for 10 s, then quench to room temperature
- (e) Rapidly cool to 550°C, hold at this temperature for 5 s, then quench to room temperature
- (f) Rapidly cool to 350°C, hold for 300 s, then quench to room temperature.
- (g) Rapidly cool to 665°C, hold for 10³ s, then quench to room temperature.
- (h) Rapidly cool to 350°C, hold for 10³ s, then guench to room temperature.

